

CARGO APRON


INSTRUCTIONS FOR INSTALLATION



INSTALL - Figure 1



INSTALL - Figure 2



INSTALL - Figure 3



INSTALL - Figure 4



INSTALL - Figure 5

STEP 1
Unfold the CarGo Apron with the closed box end against the back of the rear seats, and the flap hanging out the rear of the vehicle (Figure 1).

STEP 2
Place the cord that is at the box end over the right and left headrests (Figure 2). Use the sliding cord lock to take up any slack in the cord (Figure 4).

STEP 3
Unfold one side of the CarGo Apron, and suspend the side panel cord to the side window glass with the two suction cups. Space the suction cups, side to side, and up and down, according to the shape of the window (Figure 3). If the window has defrost element lines, the suction cups need to be placed between the lines. Repeat on the opposite side of the vehicle.

STEP 4
Pull the flap toward you to cover the bumper. Use the sliding cord lock, on each side, to take up any slack in the cord (Figure 4).

After loading, use rear hooks to secure rear flap in the up position (Figure 5).



Properly Installed CarGo Apron



REMOVAL - Figure 6



REMOVAL - Figure 7



REMOVAL - Figure 8



REMOVAL - Figure 9

INSTRUCTIONS FOR REMOVAL

STEP 1
Remove cord from headrests. Release suction cups, from windows, by pulling on small tabs. Place suction cups in the middle.

STEP 2
Fold flap into cargo area (Figure 6). Fold box end so that the side panels fold on top (Figure 7). Fold in thirds (Figure 8).

STEP 3
Roll up from rear of vehicle and secure with cord loop and sliding cord lock (Figure 9).

INSTRUCTIONS FOR INSTALLATION




INSTALL - Figure 1



INSTALL - Figure 2



INSTALL - Figure 3



INSTALL - Figure 4

STEP 1
Place the CarGo Apron in the cargo area behind the front seats and unfold toward the rear of the vehicle (Figure 1).

STEP 2
Unfold the box end and place the box end cord over the front seat headrests (Figure 2). Use the sliding cord lock to take up any slack in the cord (Figure 5).

STEP 3
Unfold one side of the CarGo Apron, and hook the front side cord over the garment hook (Figure 3). If there is no garment hook, attach the provided accessory hook and suspend from the grab handle. If there is neither a garment hook or grab handle, attach the suction cup to the door window, about half way up the glass (Figure 4).

STEP 4
Go to the rear of the vehicle and attach the suction cup to the rear side window about half way up the glass (Figure 4). Use the sliding cord lock to take up any slack in the cord (Figure 5).

Repeat steps #3 and #4 on the opposite side of the vehicle.

After loading, use rear hooks to secure rear flap in the up position (Figure 6).



INSTALL - Figure 5



INSTALL - Figure 6



Properly Installed CarGo Apron

INSTRUCTIONS FOR REMOVAL

STEP 1
Remove the cord from side garment hooks (or alternate attachment). Release suction cups by pulling on small tabs, and place in center of cargo area. Remove cord from headrests.

STEP 2
Fold flap into cargo area. Fold box end first so that the side panels fold on top (Figure 7). Fold in thirds.

STEP 3
Roll up from rear of vehicle and secure with cord loop and sliding cord lock (Figure 8).



REMOVAL - Figure 7



REMOVAL - Figure 8